


11 x 17 Flatbed Scanner Guide


To start scanning, place your artwork on the scanning bed. Then launch the Adobe Photoshop application on the Dock bar.



In Photoshop Select the following Menu path
File > Import > Epson Scanner Expression 836XL ...




The Next window that loads allows you too scan your document. First, change the “Mode” from “Home Mode” to “Professional Mode”



If all has gone well, you will have the same options appear on your screen (as shown in the graphic on the right). We recommend that you don't exceed 300 DPI for scanning your photos. We suggest using 150 DPI when scanning your photos.

Note: The higher the DPI, the bigger your file size becomes. Also, the higher DPis will cause your photo to take longer to print out.



Once you are sure that all of your settings are correct, press the “Scan” Button at the bottom of the window.

